



## MLToys Brake Reduction Module Installation

### **You will need:**

Straight head screwdriver, wire cutters and strippers

### **Installation:**

1. Access the 3 wires under the gas pedal.
2. Identify the wire coming from your foot plunger connector in the same position as we've pictured.
  - A. Power Wheels - outside wire closest to the middle connector, usually an orange wire.
  - B. Kid Trax vehicles - black wire in the same position as pictured.
  - C. Peg Perego - Blue wire. But if your car also has a brake pedal this module will not work.
3. Cut about 3" from this wire in a place where you have room to install the Brake Reduction Module. Kid Trax owners, if your black wire splits off to the radio then cut AFTER the radio split so the radio wire runs straight to the pedal still.
4. Crimp the Brake Reduction Module to the wire. It is not directional.
5. If you want to screw it to the car you can. A little bounce won't hurt it.
6. Re-assemble car.