



Dual Temperature Gauge In-Dash

Thank you for purchasing our Dual Temperature Gauge. Cut a square hole in the location you want to place the gauge, 1.75" long x 1" high. Remember to first check behind the location for things you may not want to cut such as the radio antenna wire. Insert the gauge into the hole. Splice the red and black gauge wires to the battery leads on the car. Red goes to white or red, black goes to black or blue. If you are running 24v you'll need to connect it to our Voltage Reduction Module.

Max temperature for our 550's and 775's is 170 degrees Fahrenheit. There is no minimum. Do not leave your battery plugged in when the vehicle is not in use. Even without the gauge your vehicle will slowly draw the battery down. Have fun!